



*Welcome to*

  
**candyl**

***Here's How to Get Started***



## Step 1

Fill the Jar

approx  **$\frac{3}{4}$**

with water



## Do Not Overfill

It doesn't need to be exact, but try not to fill beyond  **$\frac{3}{4}$**  full, which is about:

Designed to work with tap water.  
For best results, use distilled or filtered water.





## Step 2



**Drip into the jar**

approx **5-15** drops

**of Essential Oil**

Dilute the oil directly into the water.

**Suggested Range: 5-15 drops**

**Amounts will vary based upon:**

- Type of Essential Oil (or other liquid fragrance)
- Strength preference of the user
- Size of Room



**Warning: avoid dripping oil onto the diffuser top.  
Clean immediately to avoid discoloration.**





## Step 3

## Assembly (1+2+3)



- Feed the cotton stick into the plastic tube
- Attach both parts by aligning the cylinders and pushing snugly upwards into the diffuser top

## Step 4



## Attach Top to Jar

- \* Suction cup secures fit onto any  
Candyl 100% Ceramic Jar Base
- \* Great for other household uses  
Food, Dishwasher & Microwave Safe



**Swappable Jars**  
for fast & easy changes of style



*One diffuser... many styles*

see more at: **[candyl.co/jars](https://candyl.co/jars)**



## Step 5



**Charge the Battery**

*with 5v USB charger*

**Plug it in here**



**Charge 3 hour +**  
on first use

**Estimated Battery Life:**

**6–8 Hours** *per charge*

**Works with most 5V USB chargers.**

**Do not exceed 5V / 2.1A.**

**Battery life may vary and lessen with time.**



# Step 6

Press Button to Start

**1<sup>st</sup> Press**



Start diffusing with orange Candyl flame light.

**2<sup>nd</sup> Press** Keep diffusing without lighting.



**BLOW IT OUT**

or press a 3<sup>rd</sup> time to turn off



*In any mode,*  
**Hold-Press**

**1 2 3 seconds**



*to start* **1-hour**  
**countdown timer**  
*(automatic shutoff)*



# Help

## *Not working?*

Try these steps then contact help.

- 1 Check USB power. Try using a different USB charger.
- 2 Take all the pieces apart and restart setup to reassemble. Make sure you remove and replace the cotton stick without removing the spring.

Still need help? Contact us:

**help@candyl.co**

**candyl.co/help**

**(+1) 310-866-3807**

Video setup guide:





# Cleaning Tips

To avoid discoloration, immediately clean away an essential oil that makes contact with the top of the diffuser.

Occasionally flush the cotton sticks under a running sink or in a bowl of soapy water. *(squeeze for best results!)*

Washing occasionally between uses prevents mixing of scents and prolongs freshness of cotton sticks. Do not submerge the top.

Descaling solution, such as white vinegar, on a cotton stick or Q-tip can be used to gently remove hard water buildup from the ultrasonic plate.

Jars can be cleaned by hand or dishwasher.



# Info

## Limited Warranty

*Your diffuser is backed by a 1 year limited warranty. Regardless of where you purchased Candyl, non-working units will be replaced at no cost to the customer in the event of manufacturing defects resulting in performance failures.*

*Rather than returning to your retailer, submit your claim online to receive free shipping within the United States.*

*If you purchased from [candyl.co](http://candyl.co) or at a Candyl retail store, you may return it directly to our stores or use the warranty submission online form.*

*Claims related to physical damages should be directed to the postage carrier and/or the retailer from which the unit was purchased.*

*For more information or to submit a claim, visit:*

**[candyl.co/warranty](http://candyl.co/warranty)**



# Accessories & More

## Fresh Cotton Sticks

For best results, replace every 3 to 9 months


## Replacement Cords

Jars, Essential Oils, & more

*Available at*



**candyl.co**





candyl.co

The candle, *Re-invented*  
THE ORIGINAL FLAME DIFFUSER