



CANDYL GALAXY


Ultrasonic Diffuser




USER MANUAL



Remove the top to add water & essential oil (as desired). When adding or removing water, pour away the side shown below. Keep on a flat surface. Do not exceed the fill line of 8oz (250ml).



Remote Control Operation



Operating Instructions

- ⏻ Press the power button to start.
- 🌀 Press the mist mode button to start fireplace mode.
- 🌀 Press again to start color cycle mode.
- 🌀 Press again to stop on current color (any color mode).
- ⚙️ Press the music mode button to start music mode.
- ⚙️ Press again for alternate music pickup animation.
- ⚙️ Press again for rainbow mode (no music pickup).
- ⚙️ Press again for diffuse only mode (lights off).
- ⌚ Press timer button to start 2 hour shutoff timer.
- ⌚ Press again for to start 4 hour shutoff timer.
- ⌚ Press again for to start 6 hour shutoff timer.
- ⏻ Press the power button to turn off (at any time).

Product Detail

Power Input: USB-C 5v 1A
Tank Capacity: 8oz (250ml)
Spray Output: 20-25ml/h
Size: 9 3/4" x 3 1/2" x 3"
(25cm x 7.5cm x 8.7cm)
Weight: 13.3oz (378g)
Standard: GB4706.1-2005



Help

help@candyl.co

candyl.co/help

310-866-3807



Warranty

Your Candyl diffuser is backed by a 1-year limited warranty. Rather than returning your diffuser to the store, use the link below to file a claim to receive a free replacement.

candyl.co/warranty

