



Candyl Nordic Wax Melting Lamp User Guide

Introduction


This lamp's halogen bulb will gently heat and melt wax evenly. By making simple adjustments to the height of the lamp as well as the brightness of the bulb, you can control the melt rate and scent throw. Your candle warming lamp is a safer and easier way to enjoy wax candles and melts.



Warning:
DO NOT COVER

Read all instructions and safety measures in this manual to ensure proper and safe use.

Product Diagram



Instructions for Use

Step ①: Install the GU10-Base Lightbulb

Do not plug in the lamp yet.
Take care when handling the glass lampshade.
Do not touch the prongs.

Align the two prongs into either hole.
Insert both prongs, and turn clockwise.


Plug into power outlet.

Step ②: Adjust the Lamp Height

Place a wax candle (or wax melts in heat-safe bowl) on the platform.

Hold and brace the neck rod or horizontal rod while unscrewing counterclockwise the adjustment knob. Pull the rod upwards to shift into the highest position. Slowly lower until the bottom of the lampshade is about 2 inches from the top of the candle. Screw the knob clockwise tightly to hold the position. Adjust as needed.

Step ③: Use the In-Line Remote Control to Operate



Product Details

Power Supply: 110v / 50Hz 50W Max
IEC Shock Protection: Class II, IP20, Indoor Use Only
Operating Temperatures: 23° F - 113° F (-5° C - 45° C)
Lightbulb: Halogen GU10, 35-50W
Dimensions (LWH): 7"x 4.75"x 13" (18cm x 12cm x 33cm)

Safety Measures

While safer than lit candles, this device can still pose a fire risk and should be treated accordingly. Observe these safety measures to prevent fire or injury.

- Never light the candle wick while using the warmer lamp.
- Do not touch the lightbulb during use or 30 minutes after being on, it may reach up to 200 degrees F and may burn your skin.
- Never cover the lamp with a cloth or otherwise improvised lampshade.
- Indoor use only. Avoid placing underneath or near curtains.
- Do not expose to water or high humidity and temperatures.
- Avoid looking directly at the lightbulb.
- Unplug from power source before installing or changing a lightbulb.
- Place on flat surface only, not to exceed 6 degrees.



Please note the metal lampshade is may become hot. Handle with care. Align the lampshade over the wood base. Misalignment may result in tipping over.

Suggestions

- Use both height and brightness adjustments to achieve preferred melting temperatures. Each candle may have different melt temperatures. As the wax melts, you may need to lower the lamp and/or increase the brightness.
- If the candle doesn't melt evenly, check that the surface is flat. Then, safely pour off the first layer of melted/wax oil.
- Utilize the timer function if you may fall asleep, to avoid leaving on all night. Continuous use over 8 hours is not recommended.
- This product is intended to function as a candle or wax melting device. Some users may also find the light produced is adequate for other household lighting applications.

Help & Support

For more help and information, visit candyl.co/help
For additional support,
email contact@candyl.co
or call 310-866-3807.



Warranty

1-year limited warranty.
Do not return to store.
File claim at
candyl.co/warranty
for free replacement.



2024 Candyl LLC, Denver, CO. Made in China.